

# Podium and Tabletop Microphones



## Podium Microphone

Turn on the microphone by pressing the gray button

The green LED will light up when mic is active



## Tabletop Microphones

Turn on the microphone by holding “mic” button

The “mic” button will glow white when mic is on

Push the “mic” button once to activate the mic

The “mic” button will glow green when mic is active

Push the mic button once more to deactivate

