



Wireless Microphones


Lavalier Microphone



Use the switch to power the microphone on or off

Clip the microphone to your shirt, tie, or jacket about 6-8 inches below your chin

Handheld Microphone



Use the switch to power the microphone on or off